

## GENERAL INFORMATION


### Product Support

Product support shall be provided by VIO as long as this product is still under warranty. VIO is not obliged to provide any repairs/ replacement on defects and damages caused by improper installation, improper operation, wrongful cleaning agents that deteriorate the surface appearance, force majeure and/or modifications made by user or third party.

### Corrosion Protection

Do not expose luminaire to corrosive agents (e.g. salt, acid, chemical & cleaning agents) during installation or cleaning. These agents may cause corrosion on the luminaire.

### Sizing Variation



Product	A	B
SYMMETRY	91	75

All measurements are in millimeters.

### Cleaning and Care


Before cleaning, disconnect the luminaire from main supply and allow it to cool. Clean the external surface using lint free cloth with alcohol-free and non-abrasive cleaning agent.

### Ambient Condition

LED luminaire performs best in an ambient temperature of <35°C. High ambient temperature may reduce the lifespan and efficiency of the LED driver and luminaire.



## SYMMETRY



### Installation Manual and Safety Instruction


Please read the installation manual carefully before commencement of installation.

Before carrying out any installation, please ensure that all power is switched off and disconnected from the main power supply.


This product must be installed by a qualified installer under local regulations.

The light source of the luminaire is not replaceable. When the light source reaches its end of life, the whole luminaire shall be replaced.


1




2




3



4



5



## INSTALLATION INSTRUCTIONS

### SYMMETRY

1. Before installation or servicing, turn off and disconnect from main power supply. Detach the mounting plate from the luminaire.
2. Drill mounting holes and pull cable through mounting plate for installation. Fix the mounting plate with the provided screws. For installation on wooden boards, ensure that the thickness of the board is at least 5mm.
3. Connect the luminaire to the main power supply.
4. Attach the luminaire housing to the mounting plate.
5. Rotate and tilt the luminaire to your desired position.